

Q. I have a problem using my machine with Mac OS® X Classic mode.

A.

Your machine does not work with Mac OS® X Classic mode because your machine has Removable Disk related features and the USB storage driver is using the USB port. However, you can use the Mac OS® X directly to access Removable Disk related features or restart your computer into Mac OS® 9.x.

In order to reboot the computer into OS 9, you will need to change the Startup Disk. Please select the Startup settings from:

System Preferences => Startup Disk => Mac OS 9 System

And please reboot the Macintosh.